

TECHNICAL DATA  
SMART SYNC CONTROL

WARRANTY  
3 years guarantee

PRODUCT CODE  
T-4Z-WALL-B



@GAPLightingLtd  
GAP Lighting Ltd  
/GAPLightingLtd  
GAP Lighting Ltd



## SMART SYNC



### PRODUCT DESCRIPTION


RGB+CCT 4 Zone Touch Controller with smooth dimming function and dynamic multi colour changing programmes. For wall mounting anywhere - battery powered. Incorporating wireless RF 2.4G technology. Synchronise multiple products simultaneously or control independently up to 30m range.



SOLAS



iFlood



iFlex

To see all compatible products go to [www.gaplighting.co.uk](http://www.gaplighting.co.uk)

### PRODUCT FEATURES

- RF 2.4G remote control for Smart Sync products
- RGB colour bar for manual colour selection
- CCT bar for manual white selection
- Brightness control bar | 9 dynamic modes
- Speed control buttons for dynamic modes
- Range up to 30m
- Pair any number of Smart Sync luminaires within 30m range (without obstruction) for synchronised control
- Back plate for easy surface mounting / removal

### PRODUCT DATA

|                 |   |
|-----------------|---|
| Model           | T-4Z-WALL-B   |
| Control         | 4 zone RGB+CCT remote with touch dimming control  |
| Function        | Dimming   speed variation   dynamic colour changing modes   CCT tuneable white   single colour settings   master control function   60s delay off |
| Frequency       | 2.4GHz high frequency wireless  |
| Remote distance | up to 30 metres   |
| Dimensions      | L 80mm   W 80mm   D 19mm  |
| Material        | Glass surface   Plastic housing   |
| Working temp.   | -20 to + 60°C   |
| Power           | 2 x AAA batteries  Standby 15uA   |
| Approvals       | CE   ROHS   |



**Sync:** Switch on via the mains switch. Within 3 seconds, select a Zone-ON button and hold down. Pairing is confirmed when the fitting flashes green. If it does not flash green, try the procedure again.

**Unsync:** Switch on via the mains switch. Within 3 seconds, select the Zone-ON button that relates to the zone you wish to unsync and hold down. Unsyncing is confirmed when the fitting flashes red. If it does not flash red, try the procedure again.

You can go through the different dynamic modes by pressing 'M' and adjust the speed by pressing 'S+/S-'. Hold the Zone-ON button to select the colour white. Select 'S+/S-' to saturate the solid colours when using the colour wheel. If you are using RGB+CCT products press the **white bar** to change the colour temperature.