

TECHNICAL DATA  
SMART SYNC CONTROL

WARRANTY  
3 years guarantee

PRODUCT CODE  
T-8Z-WALL



@GAPLightingLtd  
GAP Lighting Ltd  
/GAPLightingLtd  
GAP Lighting Ltd



## SMART SYNC



### PRODUCT DESCRIPTION


RGB+CCT 8 Zone Touch Controller with smooth dimming function and dynamic multi colour changing programmes. For wall mounting anywhere - battery powered. Incorporating wireless RF 2.4G technology. Synchronise multiple products simultaneously or control independently up to 30m range.



SOLAS



iFlood



iFlex

To see all compatible products go to [www.gaplighting.co.uk](http://www.gaplighting.co.uk)

### PRODUCT FEATURES

- RF 2.4G remote control for Smart Sync products
- RGB+CCT - colour wheel and slider bar for manual colour selection
- Brightness control bar | 10 dynamic modes
- Speed control buttons for dynamic modes
- Range up to 30m
- Pair any number of Smart Sync luminaires within 30m range (without obstruction) for synchronised control
- Rechargeable batteries recommended
- Back plate for easy mounting / removal

### PRODUCT DATA

Model	T-8Z-WALL
Control	8 zone RGB+CCT remote with touch dimming control
Function	Dimming   speed variation   memory   colour saturation   dynamic colour changing modes   single colour settings   master control function
Frequency	2.4GHz high frequency wireless
Remote distance	up to 30 metres
Dimensions	L 106mm   W 146mm   D 20mm
Material	Plastic housing
Working temp.	-20 to + 60°C
Power	2 x AAA batteries   3.3vDC connector input
Approvals	CE   ROHS

### INSTRUCTIONS FOR USE



**Sync:** Select the zone you would like to sync the product to (1-8). Turn the light off via the mains switch. Turn the light on, and within 3 seconds, select the 'ON' button and tap 3 times. The light will flash 3 times which means that syncing has been completed. If the light does not flash then the syncing has failed. Please switch off the light and restart the pairing process again.

**Unsync:** Select the zone you would like to unsync the product from (1-8). Turn the light off via the mains switch, leave for 10 seconds, and turn on again. Within 3 seconds, select the 'ON' button and tap 5 times. The light will flash 10 times which means that unsyncing has been completed. If the light does not flash then the unsyncing has failed. Please switch off the light and restart the unsyncing process again.